



## CHIAVI TORX LUNGHE



CODICE	MISURA	L1	L2	CONFEZIONE
	TX	MM	MM	
<a href="#">BE2800 08</a>	08 TX	78	16	10
<a href="#">BE2800 09</a>	09 TX	82	16	10
<a href="#">BE2800 10</a>	10 TX	86	17	10
<a href="#">BE2800 15</a>	15 TX	90	18	10
<a href="#">BE2800 20</a>	20 TX	95	19	10
<a href="#">BE2800 25</a>	25 TX	100	20	10
<a href="#">BE2800 27</a>	27 TX	105	22	10
<a href="#">BE2800 30</a>	30 TX	114	24	10
<a href="#">BE2800 40</a>	40 TX	124	26	10

## SET CHIAVI TORX LUNGHE



CODICE	MISURA	N° DI CHIAVI	CONFEZIONE
<a href="#">BE2846</a>	8 - 40 TX	9 Con supporto in plastica	6

## CHIAVI TORX FORATE CORTE



CODICE	MISURA	L1	L2	CONFEZIONE
		MM	MM	
<a href="#">BE2600/R 06</a>	06 TX	51	16	10
<a href="#">BE2600/R 07</a>	07 TX	51	16	10
<a href="#">BE2600/R 08</a>	08 TX	51	16	10
<a href="#">BE2600/R 09</a>	09 TX	51	16	10
<a href="#">BE2600/R 10</a>	10 TX	54	17	10
<a href="#">BE2600/R 15</a>	15 TX	58	18	10
<a href="#">BE2600/R 20</a>	20 TX	62	19	10
<a href="#">BE2600/R 25</a>	25 TX	65	20	10
<a href="#">BE2600/R 27</a>	27 TX	68	21	10
<a href="#">BE2600/R 30</a>	30 TX	76	24	10
<a href="#">BE2600/R 40</a>	40 TX	83	26	10
<a href="#">BE2600/R 45</a>	45 TX	91	29	10

## SET CHIAVI TORX CORTE



CODICE	MISURA	N° DI CHIAVI	CONFEZIONE
<a href="#">BE2646</a>	8 - 40 TX	9 Con supporto in plastica	12
<a href="#">BE2646R</a>	8 - 40 TX Forate	9 Con supporto in plastica	12